

INSTALLATION GUIDE - AUSTRALIA

FELTON

AXISS RAIN SHOWER COLUMN AXRSCCA

SYSTEM REQUIREMENTS

To ensure the optimum performance and customer satisfaction please adhere to the following:

- Flush out all pipe work prior to installation.
- Maximum hot water temperature is 60°C. If the water temperature exceeds 60°C an approved tempering valve must be fitted.
- Installation should comply with relevant local authority requirements.
- In accordance with good plumbing practice, filters should be fitted to supply lines to eliminate damage to the ceramic cartridge from suspended solids.
- AS/NZS 3500.1 states that pressures above 500kPa can cause damage from water hammer, reduce the life of appliances, taps & fittings, cause excessive noise in the system and recommend that a pressure limiting valve (PLV) be fitted.

MAXIMUM STATIC PRESSURE

Maximum static pressure 500kPa. If water pressure exceeds or is likely to exceed 500kPa, an approved pressure limiting valve must be fitted.

MINIMUM STATIC PRESSURE

Minimum static pressure 150kPa. To ensure optimal performance the static pressure must be greater or equal to 150kPa.



Failure to comply with the above will void warranties.


WHAT IS IN THE PACK




2 x Wall Anchors



2 x Screws



1 x Hose



1 x Rain Head



2 x Flow Restrictor & Sleeve




Chrome Flange (Diverter Valve)



Bottom Chrome Flange









1 x Single Spray Handpiece



1 x Rail & Arm

HOW TO INSTALL

 <p>Mark down vertical of 550mm from centre of water outlet. Warning: Ensure no water pipe or power cable in wall at this location. IMPORTANT: The threaded water outlet must not protrude more than 10mm from wall face. Apply thread seal tape to water outlet.</p> <p>1.</p>	 <p>Loosen grub screws on body of diverter valve and lower mounting bracket and withdraw the brass easy fit.</p> <p>2.</p>	<p style="text-align: right;">TOP</p>  <p>Screw the top easy fit onto water outlet till it is flush against the wall face.</p> <p>3.</p>
<p style="text-align: right;">BOTTOM</p>  <p>Then mark and use screws to fasten bottom easy fit into place. <i>(If installing into concrete, use toggles provided. Squeeze to close each toggle and push in until flush with the wall).</i></p> <p>3.</p>	 <p>Fit chrome flange onto top and bottom bracket.</p> <p>4.</p>	 <p>Fit the entire assembly onto wall by tightening the grub screws on the bottom and top mounting bracket.</p> <p>5.</p>

